

The Electronic Monitoring System (EMS) will display an error code in the event of a fault developing in the transmission system.

The code will be displayed on the top line of the EMS display panel in the format: **ZFCB ERROR ??**

<b>Fault Code</b>	<b>Fault Detected</b>	<b>Possible Causes</b>	<b>Action</b>
12	Logical error at direction select signal	<ul style="list-style-type: none"> <li>• Cable from shift lever to TCU is broken.</li> <li>• Cable is defective and is contacted to battery voltage or earth.</li> <li>• Shift lever is defective.</li> </ul>	<ul style="list-style-type: none"> <li>• Check cables from TCU to shift lever.</li> <li>• Check signal combinations of shift lever F-N-R.</li> </ul>
25	Short circuit to battery voltage or open circuit to transmission sump temperature sensor input.	<ul style="list-style-type: none"> <li>• Cable is defective and is contacted to battery voltage or earth.</li> <li>• Cable has no connection to TCU.</li> <li>• Temperature sensor has an internal defect.</li> <li>• Connector pin is contacted to battery voltage or is broken.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the temperature sensor.</li> </ul>
26	Short circuit to earth at transmission sump temperature sensor input.	<ul style="list-style-type: none"> <li>• Cable is defective and is contacted to vehicle earth.</li> <li>• Temperature sensor has an internal defect.</li> <li>• Connector pin is contacted to vehicle earth.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the temperature sensor.</li> </ul>
27	Short circuit to battery voltage or open circuit at converter output temperature sensor input.	<ul style="list-style-type: none"> <li>• Cable is defective and is contacted to battery voltage.</li> <li>• Cable has no connection to TCU.</li> <li>• Temperature sensor has an internal defect.</li> <li>• Connector pin is contacted to battery voltage or is broken.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the temperature sensor.</li> </ul>
28	Short circuit to earth at converter output temperature sensor input.	<ul style="list-style-type: none"> <li>• Cable is defective and is contacted to vehicle earth.</li> <li>• Temperature sensor has an internal defect.</li> <li>• Connector pin is contacted to vehicle earth.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the temperature sensor.</li> </ul>
31	Short circuit battery voltage or open circuit at engine speed input.	<ul style="list-style-type: none"> <li>• Cable is defective and is contacted to battery voltage.</li> <li>• Cable has no connection to TCU.</li> <li>• Speed sensor has an internal defect.</li> <li>• Connector pin is contacted to battery voltage or is broken.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the speed sensor.</li> </ul>
32	Short circuit to earth at engine speed input.	<ul style="list-style-type: none"> <li>• Cable is defective and is contacted to vehicle earth.</li> <li>• Speed sensor has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the speed sensor.</li> </ul>

<b>Fault Code</b>	<b>Fault Detected</b>	<b>Possible Causes</b>	<b>Action</b>
33	Logical error at engine speed input.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and is contacted to vehicle earth.</li> <li>• Speed sensor has an internal defect.</li> <li>• Sensor gap is the wrong size.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the speed sensor.</li> <li>• Check the sensor gap.</li> </ul>
34	Short circuit to battery voltage or open circuit at turbine speed input.	<ul style="list-style-type: none"> <li>• Cable is defective and is contacted to battery voltage.</li> <li>• Cable has no connection to TCU.</li> <li>• Speed sensor has an internal defect.</li> <li>• Connector pin is contacted to battery voltage or has no contact.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the speed sensor.</li> </ul>
35	Short circuit to earth at turbine speed input.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and is contacted to vehicle earth.</li> <li>• Speed sensor has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the speed sensor.</li> </ul>
36	Logical error at turbine speed input.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and is contacted to vehicle earth.</li> <li>• Speed sensor has an internal defect.</li> <li>• Sensor gap is the wrong size.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the speed sensor.</li> <li>• Check the sensor gap.</li> </ul>
37	Short circuit to battery voltage or open circuit at internal speed input.	<ul style="list-style-type: none"> <li>• Cable is defective and is contacted to battery voltage.</li> <li>• Cable has no connection to TCU.</li> <li>• Speed sensor has an internal defect.</li> <li>• Connector pin is contacted to battery voltage or has no contact.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the speed sensor.</li> </ul>
38	Short circuit to earth at internal speed input.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and is contacted to vehicle earth.</li> <li>• Speed sensor has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the speed sensor.</li> </ul>
39	Logical error at internal speed input.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and is contacted to vehicle earth.</li> <li>• Speed sensor has an internal defect.</li> <li>• Sensor gap is the wrong size.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the speed sensor.</li> <li>• Check the sensor gap.</li> </ul>
3A	Short circuit to battery voltage or open circuit at output speed input.	<ul style="list-style-type: none"> <li>• Cable is defective and is contacted to battery voltage.</li> <li>• Cable has no connection to TCU.</li> <li>• Speed sensor has an internal defect.</li> <li>• Connector pin is contacted to battery voltage or has no contact.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the speed sensor.</li> </ul>

<b>Fault Code</b>	<b>Fault Detected</b>	<b>Possible Causes</b>	<b>Action</b>
3B	Short circuit to earth at output speed input.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and is contacted to vehicle earth.</li> <li>• Speed sensor has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the speed sensor.</li> </ul>
3C	Logical error at output speed input.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and is contacted to vehicle earth.</li> <li>• Speed sensor has an internal defect.</li> <li>• Sensor gap is the wrong size.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the connectors.</li> <li>• Check the speed sensor.</li> <li>• Check the sensor gap.</li> </ul>
3E	Output speed zero does not fit to other speed signals.	<ul style="list-style-type: none"> <li>• Speed sensor has an internal defect.</li> <li>• Sensor gap is the wrong size.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the sensor.</li> <li>• Check the sensor signal of the output speed sensor..</li> <li>• Check the sensor gap of the output speed sensor.</li> </ul>
54	EMS & ZF computer not communicating via the CAN-Bus.	<ul style="list-style-type: none"> <li>• Interference on CAN-Bus.</li> <li>• CAN wire/connector is broken.</li> <li>• CAN wire/connector is defective and has contact with vehicle earth or battery voltage.</li> </ul>	<ul style="list-style-type: none"> <li>• Check cluster controller.</li> <li>• Check wire of CAN-Bus.</li> <li>• Check cable to cluster controller.</li> </ul>
71	Short circuit to battery voltage at clutch K1.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and is contacted to battery voltage.</li> <li>• Cable/connector is defective and has contact to another regulator output of the TCU.</li> <li>• Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the gearbox.</li> <li>• Check the connectors from TCU to the gearbox.</li> <li>• Check the regulator resistance.</li> <li>• Check the internal wire harness of the gearbox.</li> </ul>
72	Short circuit to earth at clutch K1.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and is contacted to vehicle earth.</li> <li>• Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the gearbox.</li> <li>• Check the connectors from TCU to the gearbox.</li> <li>• Check the regulator resistance.</li> <li>• Check the internal wire harness of the gearbox.</li> </ul>
73	Open circuit at clutch K1.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and has no contact to TCU.</li> <li>• Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the gearbox.</li> <li>• Check the connectors from TCU to the gearbox.</li> <li>• Check the regulator resistance.</li> <li>• Check the internal wire harness of the gearbox.</li> </ul>
74	Short circuit to battery voltage at clutch K2.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and has contact to battery voltage.</li> <li>• Cable/connector is defective and has contact to another regulator output of the TCU.</li> <li>• Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the gearbox.</li> <li>• Check the connectors from TCU to the gearbox.</li> <li>• Check the regulator resistance.</li> <li>• Check the internal wire harness of the gearbox.</li> </ul>

Fault Code	Fault Detected	Possible Causes	Action
75	Short circuit to earth at clutch K2.	<ul style="list-style-type: none"> <li>Cable/connector is defective and has contact to vehicle earth.</li> <li>Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>Check the cable from TCU to the gearbox.</li> <li>Check the connectors from TCU to the gearbox.</li> <li>Check the regulator resistance.</li> <li>Check the internal wire harness of the gearbox.</li> </ul>
76	Open circuit at clutch K2.	<ul style="list-style-type: none"> <li>Cable/connector is defective and has no contact to TCU.</li> <li>Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>Check the cable from TCU to the gearbox.</li> <li>Check the connectors from TCU to the gearbox.</li> <li>Check the regulator resistance.</li> <li>Check the internal wire harness of the gearbox.</li> </ul>
77	Short circuit to battery voltage at clutch K3.	<ul style="list-style-type: none"> <li>Cable/connector is defective and has contact to battery voltage.</li> <li>Cable/connector is defective and has contact to another regulator output of the TCU.</li> <li>Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>Check the cable from TCU to the gearbox.</li> <li>Check the connectors from TCU to the gearbox.</li> <li>Check the regulator resistance.</li> <li>Check the internal wire harness of the gearbox.</li> </ul>
78	Short circuit to earth at clutch K3.	<ul style="list-style-type: none"> <li>Cable/connector is defective and is contacted to vehicle earth.</li> <li>Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>Check the cable from TCU to the gearbox.</li> <li>Check the connectors from TCU to the gearbox.</li> <li>Check the regulator resistance.</li> <li>Check the internal wire harness of the gearbox.</li> </ul>
79	Open circuit at clutch K3.	<ul style="list-style-type: none"> <li>Cable/connector is defective and has no contact to TCU.</li> <li>Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>Check the cable from TCU to the gearbox.</li> <li>Check the connectors from TCU to the gearbox.</li> <li>Check the regulator resistance.</li> <li>Check the internal wire harness of the gearbox.</li> </ul>
81	Short circuit to battery voltage at clutch K4.	<ul style="list-style-type: none"> <li>Cable/connector is defective and has contact to battery voltage.</li> <li>Cable/connector is defective and has contact to another regulator output of the TCU.</li> <li>Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>Check the cable from TCU to the gearbox.</li> <li>Check the connectors from TCU to the gearbox.</li> <li>Check the regulator resistance.</li> <li>Check the internal wire harness of the gearbox.</li> </ul>
82	Short circuit to earth at clutch K4.	<ul style="list-style-type: none"> <li>Cable/connector is defective and is contacted to vehicle earth.</li> <li>Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>Check the cable from TCU to the gearbox.</li> <li>Check the connectors from TCU to the gearbox.</li> <li>Check the regulator resistance.</li> <li>Check the internal wire harness of the gearbox.</li> </ul>
83	Open circuit at clutch K4.	<ul style="list-style-type: none"> <li>Cable/connector is defective and has no contact to TCU.</li> <li>Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>Check the cable from TCU to the gearbox.</li> <li>Check the connectors from TCU to the gearbox.</li> <li>Check the regulator resistance.</li> <li>Check the internal wire harness of the gearbox.</li> </ul>

<b>Fault Code</b>	<b>Fault Detected</b>	<b>Possible Causes</b>	<b>Action</b>
84	Short circuit to battery voltage at clutch KV.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and has contact to battery voltage.</li> <li>• Cable/connector is defective and has contact to another regulator output of the TCU.</li> <li>• Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the gearbox.</li> <li>• Check the connectors from TCU to the gearbox.</li> <li>• Check the regulator resistance.</li> <li>• Check the internal wire harness of the gearbox.</li> </ul>
85	Short circuit to earth at clutch KV.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and is contacted to vehicle earth.</li> <li>• Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the gearbox.</li> <li>• Check the connectors from TCU to the gearbox.</li> <li>• Check the regulator resistance.</li> <li>• Check the internal wire harness of the gearbox.</li> </ul>
86	Open circuit at clutch KV.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and has no contact to TCU.</li> <li>• Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the gearbox.</li> <li>• Check the connectors from TCU to the gearbox.</li> <li>• Check the regulator resistance.</li> <li>• Check the internal wire harness of the gearbox.</li> </ul>
87	Short circuit to battery voltage at clutch KR.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and has contact to battery voltage.</li> <li>• Cable/connector is defective and has contact to another regulator output of the TCU.</li> <li>• Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the gearbox.</li> <li>• Check the connectors from TCU to the gearbox.</li> <li>• Check the regulator resistance.</li> <li>• Check the internal wire harness of the gearbox.</li> </ul>
88	Short circuit to earth at clutch KR.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and is contacted to vehicle earth.</li> <li>• Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the gearbox.</li> <li>• Check the connectors from TCU to the gearbox.</li> <li>• Check the regulator resistance.</li> <li>• Check the internal wire harness of the gearbox.</li> </ul>
89	Open circuit at clutch KR.	<ul style="list-style-type: none"> <li>• Cable/connector is defective and has no contact to TCU.</li> <li>• Regulator has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the gearbox.</li> <li>• Check the connectors from TCU to the gearbox.</li> <li>• Check the regulator resistance.</li> <li>• Check the internal wire harness of the gearbox.</li> </ul>
91	Short circuit to earth at the reverse warning alarm relay.	<ul style="list-style-type: none"> <li>• Cable is defective and is contacted to vehicle earth.</li> <li>• Backup alarm device has an internal defect.</li> <li>• Connector pin is connected to vehicle earth.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the backup alarm device.</li> <li>• Check the connectors from backup alarm device to the TCU.</li> <li>• Check the resistance of the backup alarm device.</li> </ul>
92	Short circuit to battery voltage at the alarm warning relay.	<ul style="list-style-type: none"> <li>• Cable is defective and is contacted to battery voltage.</li> <li>• Backup alarm device has an internal defect.</li> <li>• Connector pin is connected to battery voltage.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the cable from TCU to the backup alarm device.</li> <li>• Check the connectors from backup alarm device to the TCU.</li> <li>• Check the resistance of the backup alarm device.</li> </ul>

Fault Code	Fault Detected	Possible Causes	Action
93	Open circuit at the reverse warning alarm relay.	<ul style="list-style-type: none"> <li>Cable is defective and has no connection to the TCU.</li> <li>Backup alarm device has an internal defect.</li> <li>Connector has no connection to the TCU.</li> </ul>	<ul style="list-style-type: none"> <li>Check the cable from TCU to the backup alarm device.</li> <li>Check the connectors from backup alarm device to the TCU.</li> <li>Check the resistance of the backup alarm device.</li> </ul>
97	Short circuit to earth at park brake solenoid.	<ul style="list-style-type: none"> <li>Cable is defective and is contacted to vehicle earth.</li> <li>Park brake solenoid has an internal defect.</li> <li>Connector pin is connected to vehicle earth.</li> </ul>	<ul style="list-style-type: none"> <li>Check the cable from TCU to the park brake solenoid.</li> <li>Check the connectors from the park brake solenoid to the TCU.</li> <li>Check the resistance of the park brake solenoid.</li> </ul>
98	Short circuit to battery voltage at park brake solenoid.	<ul style="list-style-type: none"> <li>Cable is defective and is contacted to battery voltage.</li> <li>Park brake solenoid has an internal defect.</li> <li>Connector pin is connected to battery voltage.</li> </ul>	<ul style="list-style-type: none"> <li>Check the cable from TCU to the park brake solenoid.</li> <li>Check the connectors from the park brake solenoid to the TCU.</li> <li>Check the resistance of the park brake solenoid.</li> </ul>
99	Open circuit at park brake solenoid.	<ul style="list-style-type: none"> <li>Cable is defective and has no connection to the TCU.</li> <li>Park brake solenoid has an internal defect.</li> <li>Connector has no connection to the TCU.</li> </ul>	<ul style="list-style-type: none"> <li>Check the cable from TCU to the park brake solenoid.</li> <li>Check the connectors from the park brake solenoid to the TCU.</li> <li>Check the resistance of the park brake solenoid.</li> </ul>
B1	Slippage at clutch K1.	<ul style="list-style-type: none"> <li>Low pressure at clutch K1.</li> <li>Low main pressure.</li> <li>Wrong signal at internal speed sensor.</li> <li>Wrong signal at output speed sensor.</li> <li>Wrong size of the sensor gap.</li> <li>Clutch is defective.</li> </ul>	<ul style="list-style-type: none"> <li>Check pressure at clutch K1.</li> <li>Check main pressure in the system.</li> <li>Check sensor gap at internal speed sensor.</li> <li>Check sensor gap at output speed sensor.</li> <li>Check signal at internal speed sensor.</li> <li>Check signal at output speed sensor.</li> <li>Replace clutch.</li> </ul>
B2	Slippage at clutch K2.	<ul style="list-style-type: none"> <li>Low pressure at clutch K2.</li> <li>Low main pressure.</li> <li>Wrong signal at internal speed sensor.</li> <li>Wrong signal at output speed sensor.</li> <li>Wrong size of the sensor gap.</li> <li>Clutch is defective.</li> </ul>	<ul style="list-style-type: none"> <li>Check pressure at clutch K2.</li> <li>Check main pressure in the system.</li> <li>Check sensor gap at internal speed sensor.</li> <li>Check sensor gap at output speed sensor.</li> <li>Check signal at internal speed sensor.</li> <li>Check signal at output speed sensor.</li> <li>Replace clutch.</li> </ul>

<b>Fault Code</b>	<b>Fault Detected</b>	<b>Possible Causes</b>	<b>Action</b>
B3	Slippage at clutch K3.	<ul style="list-style-type: none"> <li>• Low pressure at clutch K3.</li> <li>• Low main pressure.</li> <li>• Wrong signal at internal speed sensor.</li> <li>• Wrong signal at output speed sensor.</li> <li>• Wrong size of the sensor gap.</li> <li>• Clutch is defective.</li> </ul>	<ul style="list-style-type: none"> <li>• Check pressure at clutch K3.</li> <li>• Check main pressure in the system.</li> <li>• Check sensor gap at internal speed sensor.</li> <li>• Check sensor gap at output speed sensor.</li> <li>• Check signal at internal speed sensor.</li> <li>• Check signal at output speed sensor.</li> <li>• Replace clutch.</li> </ul>
B4	Slippage at clutch K4.	<ul style="list-style-type: none"> <li>• Low pressure at clutch K4.</li> <li>• Low main pressure.</li> <li>• Wrong signal at internal speed sensor.</li> <li>• Wrong signal at output speed sensor.</li> <li>• Wrong size of the sensor gap.</li> <li>• Clutch is defective.</li> </ul>	<ul style="list-style-type: none"> <li>• Check pressure at clutch K4.</li> <li>• Check main pressure in the system.</li> <li>• Check sensor gap at internal speed sensor.</li> <li>• Check sensor gap at output speed sensor.</li> <li>• Check signal at internal speed sensor.</li> <li>• Check signal at output speed sensor.</li> <li>• Replace clutch.</li> </ul>
B5	Slippage at clutch KV.	<ul style="list-style-type: none"> <li>• Low pressure at clutch KV.</li> <li>• Low main pressure.</li> <li>• Wrong signal at internal speed sensor.</li> <li>• Wrong signal at turbine speed sensor.</li> <li>• Wrong size of the sensor gap.</li> <li>• Clutch is defective.</li> </ul>	<ul style="list-style-type: none"> <li>• Check pressure at clutch KV.</li> <li>• Check main pressure in the system.</li> <li>• Check sensor gap at internal speed sensor.</li> <li>• Check sensor gap at turbine speed sensor.</li> <li>• Check signal at internal speed sensor.</li> <li>• Check signal at turbine speed sensor.</li> <li>• Replace clutch.</li> </ul>
B6	Slippage at clutch KR.	<ul style="list-style-type: none"> <li>• Low pressure at clutch KR.</li> <li>• Low main pressure.</li> <li>• Wrong signal at internal speed sensor.</li> <li>• Wrong signal at turbine speed sensor.</li> <li>• Wrong size of the sensor gap.</li> <li>• Clutch is defective.</li> </ul>	<ul style="list-style-type: none"> <li>• Check pressure at clutch KR.</li> <li>• Check main pressure in the system.</li> <li>• Check sensor gap at internal speed sensor.</li> <li>• Check sensor gap at turbine speed sensor.</li> <li>• Check signal at internal speed sensor.</li> <li>• Check signal at turbine speed sensor.</li> <li>• Replace clutch.</li> </ul>
B7	Excessively hot sump.	<ul style="list-style-type: none"> <li>• Measure temperature of oil in the sump is above allowed maximum.</li> </ul>	<ul style="list-style-type: none"> <li>• Cool down machine.</li> <li>• Check oil level.</li> <li>• Check temperature sensor.</li> </ul>
B8	Excessively hot converter output.	<ul style="list-style-type: none"> <li>• Measure temperature of the oil at the converter output is above allowed maximum.</li> </ul>	<ul style="list-style-type: none"> <li>• Cool down machine.</li> <li>• Check oil level.</li> <li>• Check temperature sensor.</li> </ul>



Fault Code	Fault Detected	Possible Causes	Action
D1	Short circuit to battery voltage at power supply for sensors.	<ul style="list-style-type: none"> <li>The TCU measures more than 6V at the pin AU1 (5V sensor supply).</li> </ul>	<ul style="list-style-type: none"> <li>Check cables and connectors to sensors, which are supplied from AU1.</li> <li>Check the power supply at the pin AU1 (should be approx.. 5V).</li> </ul>
D2	Short circuit to earth at power supply for sensors.	<ul style="list-style-type: none"> <li>The TCU measures less than 4V at the pin AU1 (5V sensor supply).</li> </ul>	<ul style="list-style-type: none"> <li>Check cables and connectors to sensors, which are supplied from AU1.</li> <li>Check the power supply at the pin AU1 (should be approx.. 5V).</li> </ul>
D3	Low power at battery.	<ul style="list-style-type: none"> <li>Measured voltage at power supply is less than 24V.</li> </ul>	<ul style="list-style-type: none"> <li>Check power supply battery.</li> <li>Check cables from batteries to TCU.</li> <li>Check connectors from batteries to TCU.</li> </ul>
D4	High power at battery.	<ul style="list-style-type: none"> <li>Measured voltage at power supply is more than 24V.</li> </ul>	<ul style="list-style-type: none"> <li>Check power supply battery.</li> <li>Check cables from batteries to TCU.</li> <li>Check connectors from batteries to TCU.</li> </ul>
D5	Error at switch 1 for valve power supply VPS1.	<ul style="list-style-type: none"> <li>Cable or connectors are defective and are contacted to battery voltage.</li> <li>Cable or connectors are defective and are contacted to vehicle earth.</li> <li>Permanent power supply KL30 missing.</li> </ul>	<ul style="list-style-type: none"> <li>Check fuse.</li> <li>Check cables from gearbox to TCU.</li> <li>Check connectors from gearbox to TCU.</li> <li>Replace TCU.</li> </ul>
D6	Error at switch 2 for valve power supply VPS2.	<ul style="list-style-type: none"> <li>Cable or connectors are defective and are contacted to battery voltage.</li> <li>Cable or connectors are defective and are contacted to vehicle earth.</li> <li>Permanent power supply KL30 missing.</li> </ul>	<ul style="list-style-type: none"> <li>Check fuse.</li> <li>Check cables from gearbox to TCU.</li> <li>Check connectors from gearbox to TCU.</li> <li>Replace TCU.</li> </ul>
E3	Short circuit to battery voltage at display output.	<ul style="list-style-type: none"> <li>Cable or connectors are defective and are contacted to battery voltage.</li> <li>display has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>Check cables from TCU to the display.</li> <li>Check the connectors at the display.</li> <li>Change display.</li> </ul>
E4	Short circuit to earth at display output.	<ul style="list-style-type: none"> <li>Cable or connectors are defective and are contacted to vehicle earth.</li> <li>display has an internal defect.</li> </ul>	<ul style="list-style-type: none"> <li>Check cables from TCU to the display.</li> <li>Check the connectors at the display.</li> <li>Change display.</li> </ul>
F1	General EEPROM fault.	<ul style="list-style-type: none"> <li>TCU is defective.</li> </ul>	<ul style="list-style-type: none"> <li>Replace TCU.</li> </ul>
F2	Configuration lost.	<ul style="list-style-type: none"> <li>interference during saving data on non volatile memory.</li> <li>TCU is brand new or from another vehicle.</li> </ul>	<ul style="list-style-type: none"> <li>Reprogramme the correct configuration for the vehicle (eg. with cluster controller).</li> </ul>



<b>Fault Code</b>	<b>Fault Detected</b>	<b>Possible Causes</b>	<b>Action</b>
F3	Application error.	<ul style="list-style-type: none"><li>• Something in the application is wrong.</li></ul>	<ul style="list-style-type: none"><li>• Replace TCU.</li></ul>
F5	Clutch failure.	<ul style="list-style-type: none"><li>• One of the AEB values is out of limit.</li></ul>	<ul style="list-style-type: none"><li>• Check clutch.</li></ul>
F6	Clutch adjustment data lost.	<ul style="list-style-type: none"><li>• interference during saving data on non volatile memory.</li><li>• TCU is brand new or from another vehicle.</li></ul>	<ul style="list-style-type: none"><li>• Execute AEB.</li></ul>